

# Install Instructions

## PRP Seats

### Can-Am Maverick R

### Door-Bags Installation



**These instructions cover both the Upper and Lower Door Bags for the Maverick R**

**Read through all of the instructions completely before beginning the install.**

**Parts Included:**

**A. Door Bags (Upper or Lower)**

1 x Can-Am Maverick R Door Bag (Right)

1 x Can-Am Maverick R Door Bag (Left)

**B. Hardware**

10 x Push Pins

**Remove all parts from the bags and lay out the pieces.**

**Tools Needed:** (not included)

7/32" Drill Bit

Drill

Thumbs

**Time:**

Approx 30 Minutes.





### 1. Find the Indent Locations on the Door.

On the stock Can-Am Door there are (5) small indent-divets in the plastic that line up with the cut holes in the PRP Bags. These are the locations where you will drill a hole for the push-pins.



### 2. Use a 7/32" drill bit to create holes in the door plastic that the push-pins will go into.

\*Only go into the door about 1/4" depth (or until you feel it pop through the inner door plastic). Do not over drill or you will create a hole in the front of the door skin.



### 3. NOTE- Upper Door Bags Missing Divot

Some of the Upper Door locations do not seem to have all the divot-indent on one of the top locations, If this happens - just place the PRP bag on the door, line up all the other pin locations, and use a marker to mark the spot that the last pin should go. Then drill it out.



### 4. Install the Push-Pins

Open up the zipper of the bag, and push all the push-pins through the cut holes in the wall of the bag. Then place the bag on the door and line up those pins.



## 5. Install the Bag to the Door

Line up all the push-pins to the holes in the door, and push hard to insert them all in until the pins are flush.

Repeat the same steps for the other bags.



## 6. And you're all set!

If you have any questions or experience issues, please contact your retail outlet first for assistance. However, the staff at PRP is always happy to help at **1-800-317-6253**, or email **customerservice@prpseats.com**

**Thank you! Ride Safe!**