

Install Instructions

PRP Seat Covers for Can-Am Defender



Parts



Read through all of the instructions completely before beginning the install.

Parts Included:

A. Seat Covers

- 1 x Driver Top Cover
- 1 x Driver Bottom Cover
- 1 x Passenger Top Cover
- 1 x Passenger Bottom Cover
- 1 x Center Top Cover
- 1 x Center Bottom Cover

Tools Needed: (not included)

- T20 Torx Bit
- 2 x Hands with Opposable Thumbs (Required)

Time:

Approx 1 Hours.

Note:

To make installation easier, we highly suggest laying the PRP covers out in the sun just before install. This allows the covers to warm up, and allows the material to stretch easier when installing.



1. **Unbox the Covers and Lay Them Out**

Make sure you have all the covers, and lay them out in the sun to warm up and allow the material to stretch easier.

Front/Rear - These covers can be installed in either the front or rear rows on 4-door Defenders.

2. **Bottom Cover Installation**

The Bottom Covers are driver and passenger side specific. The cover has a larger band section on the door side that matches the larger bolster on the seat. So make sure you have the correct side cover.

Make sure the cover is facing the correct way (Hint- the PRP Patch should be on the front edge).

3. **Attach Bottom Straps**

Flip the seat cushion up, and attach the straps underneath with the hook 'n loop strips.

-Non-Sliding Seats: Make sure to run the strap above the metal bar (closer to the plastic). Otherwise it will pop off when you fold the seat.

-Driver Sliding Seat - Run the straps on the outside of the metal seat sliders. That way they dont get in the way of the slider handle.

4. **Adjust the Cover Until Tight**

Move and adjust the cover as needed so that all the corners line up correctly. Pull down on all the edges until the top of the cover is tight.

Note: There may be some wrinkles and creases from when the cover was stored in the box. After some time these will go away as the covers warm up and stretch out.



5. **Top Cover Installation**

Grab a top cover and make sure the cover is facing the correct way to match the pattern on the seat (the cutouts on the cover should be on the bottom). Driver and Passenger Side Top Covers are the same.

Start by placing the cover over the top of the seat, and wrapping the edges around the cushion.

6. **Passenger Side**

You can pull hard on the top of the cover, and pop off the top cushion. Continue to tuck the cover edges around the sides of the cushions and pull everything tight.

Connect the straps behind the cushion with the hook 'n loop strips. Then pop the cushion back onto the seat.

On the bottom edge of the cushion there are (2x)square tubes. The cover has (2x) cutouts for these tubes, and an elastic band that goes right across the gap. Tuck in all the cover edges, then take that elastic band and tuck/push it up into the gap between the cushion and the metal bar. This will help hold the cover in place and keep it tight.



7. **Driver Side**

On the Driver Side you can complete the exact same steps as the passenger. But to pop off the back cushion you need to slide the seat forward to access and remove (2x) bolts with a T20 socket.

Install the cover and get it on tight. Re-install the back cushion with those (2x) bolts and a T20 Socket. Then tuck in the bottom elastic band into the gap next to the square tubes.

Adjust both covers as needed until they fit tight and look good.





Center Cushions Installation

8. Top Cover

Fold down the armrest so that you can see the cupholders. On the rear of the armrest there are two hinges. Remove the (2x) Cotter Pins from the bolts, then remove the (2x) bolts and take the armrest completely off.

Start by placing the cover over the back of the armrest first. There are several cut slots in the cover that match up with the hinges. Take the elastic bands and pull them over the hinges so they rest on top. This will hold the cover in place and prevent it from moving.

Pull the cover over the front of the armrest and install it. Continue to pull and adjust the cover so that it is sitting correctly and tight.

Then re-install the armrest by lining up the hinges, placing the (2x) bolts back in, and re-installing the (2x) cotter pins.

9. Bottom Cover

Place the cover on top of the seat. Make sure the cover is facing the correct direction. (Hint - there is a split/seam on the vinyl band of the cover that should be on the front of the cushion.

Place the cover on top of the seat, and start by tucking in the rear of the cover first.

Then work around the edges and pull the front corners over the cushion. Adjust and push/pull the cover as needed until it is centered and tight.



10. ... And You're All Done!

If you have any questions or experience issues, please contact your retail outlet first for help. However, the staff at PRP Seats is always happy to assist you.

1-800-317-6253.

customerservice@prpseats.com

Thank you! Drive safe!

